

Coin Shackles by TCC

A signed coin, securely bound and trapped by rubber bands, is instantly liberated and appears in the hands of the audience.

The magician places a borrowed and signed coin in the center of a hollow wooden frame. Both sides are covered and sealed with transparent sheets, securely locked with 4 rubber bands.

The entire unit is then wrapped in a handkerchief. In an instant, the coin escapes from its shackles, appearing in another location.

Known by various names such as "Coin Escape" and "Crystal Coin Case", this effect has a rich history and is easy to perform, making it a staple in beginner's magic kits.

With an ebony wooden frame, the **Coin Shackles** becomes a better version suitable for gifting for beginners or long-term performances.

What's Included:

- 1x Ebony wood frame, 50mm x 50mm x 4mm, hole diameter 35mm
- 2x Transparent PVC sheets, 56mm x 56mm x 0.5mm
- 8x White rubber bands, diameter 20mm
- 1x Black handkerchief, 27cm x 27cm

Note: *Measurements are taken manually. There may be slight size variations that do not affect functionality*