

Cigarette Dispenser Box

Here is an elegant table cigarette holder, carefully crafted in Teak wood, suitable for those who love smoking in style! The cigarettes pop out of the cigarette case one at a time, positioning themselves, almost magically, vertically so they can be conveniently picked up, simply by pressing and releasing the inclined top part of the cigarette case!

- The cigarette holder, complete with top cover, measures cm 11.2 (4,4") x 6 (2,36") x 12 (4,7") .
- The inside space of the upper compartment is cm 4.8 (1,89") wide and cm 8.6 (3,38") long. Allows you to load approximately 6 cigarettes at a time.